



TWO CARD SYSTEM PERSONAL/VEHICLE

FIRST

1. Insert Personal Card, wait for the second light to turn on, then remove your Personal Card.

SECOND

2. Insert Vehicle Card.

ODO/HOUR METER

3. Enter your ending vehicle mileage reading, after mileage is entered, press the (#) button,

SELECT

4. Select a Pump Number 1 thru 8 on the key pad
Then push the (#) button.

5. Remove Vehicle RUSCO CARD.

HOSE READY

6. You are ready to pump your fuel.

There is a fee (*eight dollars*) for **damaged lost or stolen Personal/Vehicle RUSCO CARDS.**

When a person is terminated or resigns for any reason, please return **RUSCO CARD(s)** to any of the Fleet Management Departments, located in Window Rock, Chinle, Tuba City, Shiprock and Crownpoint.

If a person transfers to another department, please have your **Tribal Permit** renewed at the Hiway Safety Department before Personal **RUSCO CARD** can be activated. Any questions please call Bertie at (928) 871-7029. Thank you.